



INSTRUCTIONS:

1. PRINT PDF OUT ON
8.5"X11" STANDARD PAPER
AT 100% SCALE

2. CUTOUT THE FLAT
PATTERN WITH SCISSORS

3. USE SPRAY ADHESIVE TO
ATTACH THE FLAT PATTERN
TO CARBOARD OR THICK
PAPER

4. BEND THE FLAT PATTERN
ALONG THE BEND LINES

5. TAPE ALL THE SEAMS