


Boost set to 12v

Relay(left) Activated on LOW signal.

Pin 4 (Green(Pwr\_ON)) of motherboard is 3.3v when board is off. 0v when board is ON.


Pin 3(Grey(PWR\_ID)) of motherboard connects to grey PWR\_OK of ATX.

Can use any 12v lines (ATX, GPU, Sata) to power board. Is easiest to split the CPU 8 pin into two connecting one side to connector by CPU and the other to the relay.



4 pin power connector on board left by NVME(SSD) slot needs 12v to turn on board/make power button function. Original HP PSU always supplies 12v.


Some ATX PSU's have low current on the purple 5v bus. Recommended 2 amp minimum.



Pin 4 (Green(Pwr\_ON)) of motherboard is 3.3v when board is off. 0v when board is ON.

Pin 3(Grey(PWR\_ID)) of motherboard connects to grey PWR\_OK of ATX.

Can use any 12v lines (ATX, GPU, Sata) to power board. Is easiest to split the CPU 8 pin into two connecting one side to connector by CPU and the other to the relay.



4 pin power connector on board left by NVME(SSD) slot needs 12v to turn on board/make power button function. Original HP PSU always supplies 12v.

Some ATX PSU's have low current on the purple 5v bus. Recommended 2 amp minimum.