



Note: Trim end of each off at 23° so they will support top back brace level to the ground.