

1.

Adjust this value to your tabletop thickness.
Use a ruler and pen to adjust the drawing.

34 mm

2.

When cuttin out, leave theses black lines
standing to make sure the clamp length
is not getting to long.

3.

When sanding, sand primarily
on the insides until you can slide
the holder fully onto your desk.
This way you will get a clamping effect.

