






Identifiez et fraisez
les trous indiqués
en rouge



1




2






4x Vis
10mm Ø3




4


Boutons x16
Joysticks x2

8x Vis à tête ronde
+ écrou 40mm Ø4




5






Annexe Xin-mo 2 Players Interface


Xin-mo with standard USB
(36 pins)



Xin-mo with micro USB
(44 pins)



STICK ARCADE 2 PLAYERS




Player 2

■ Put GND on all P1 button/joystick

Player 1

■ Put GND on all P2 button/joystick



Player 2


■ Put GND on all P1 button/joystick

Player 1

■ Put GND on all P2 button/joystick

Annexe Switch option

Stick with switch



Stick without switch

