

# Papercraft LED Whirlybird Rotor Blades

With your whirlybird body and LED circuit assembled and verified to be working, print this template sheet out ON HEAVY CARDSTOCK. Cut out one of the rotor blades below with a scissors (there are extras in case your first one gets beat up over time). Then carefully remove the 3 slots with a craft knife. Afterward, fold on the dotted lines in the directions indicated for each specific fold. With the rotor blade cut and folded, continue following guide steps.

