



To Multitrigger3
Power in Socket,
Red wire +V

To Multitrigger 3
power switch
yellow wire 0V

If using MultiTrigger 3+ connect to
PHONO Pulse

Centre pin
To MultiTrigger 3 TEST
Outer

Arduino 16X2 LCD
with I2C serial
board

Outer
To Astrosplash
Centre pin

Lead for Astrosplash must be connected to the
Arduino Nano (even if not connected to
AstroSplash).
Alternate if AstroSplash is never to be used is
connect D3 on Nano to GND.

A4-----SDA
A5-----SCL